


**INSTALLATION OF FLOOR CHANNEL INTO 'D' SERIES GULLY BODY WITH C.D10L COLLAR.**

Install channel generally in accordance with drawing 'Instal 7' connecting outlet to body as follows.

1. Ensure that cast iron clamp collar is the non-threaded version (C.D10L).
2. Position gully body and fix into place.
3. Dress membrane over and into body as shown and then fix cast iron collar using the screws provided such that it clamps the membrane.
4. Lower channel outlet spigot through the opening in the membrane clamp collar setting the channel at the required FFL.

© 2006

ISS. No.		DRAWN	DC	3-2-06	TITLE TYPICAL INSTALLATION OF FLOOR CHANNELS INTO 'D' SERIES GULLY BODY.		
C.N. No.		CHECKED					
DATE		APPRVD.					
	MATERIAL	50910011#2			SCALE NTS	DRG. No. <b>INSTAL 13</b> SHEET 2 OF 2	ISSUE No. 6

WADE INTERNATIONAL LTD., THIRD AVENUE, HALSTEAD, ESSEX, CO9 2SX.

TEL: 01787 475151 FAX: 01787 475579

e-mail: tech@wade.eu website: www.wade.eu