


Installation

1. Apply silicone sealant to flange faces prior to bolting channel sections together.
2. Lower channel into position, supporting where needed to ensure that top edge is at FFL.
3. Make pipework connection.
4. Cut lengths of timber to grating width and wedge across channel at approx. 500mm centres, to prevent channel from being squeezed during pouring.
5. Lay weighted timbers across channel at FFL to prevent lifting during pouring.
6. Dress membrane onto flange following manufacturers instructions, take care not to obstruct drainage slots.
7. Pour screed / bedding.
8. Lay finished floor.
9. Fit gratings

© 2003

ISS. No.		DRAWN	M.S	29.10.03	TITLE TYPICAL INSTALLATION STAINLESS STEEL SSD/DSD CHANNELS		
C.N. No.		CHECKED					
DATE		APPRVD.					
		MATERIAL 50910022			SCALE NTS	DRG. No. INSTAL 23	ISSUE No. 3

WADE INTERNATIONAL LTD., THIRD AVENUE, HALSTEAD, ESSEX, CO9 2SX.

TEL: 01787 475151 FAX: 01787 475579

e-mail: tech@wade.eu web site: www.wade.eu