

Installation Instructions

Fit body into floor as required (illustration shows a typical installation in a timber deck).

Dress membrane such that it does not extend beyond the sloping face of the body / membrane clamp collar.

Remove the threaded ring from the clamp collar assembly using the tool provided.

Fit the clamp collar, with the supplied gasket directly below it, into the body using 3 screws provided.

Refit the threaded ring into the clamp collar using tool provided.

Fit Vari-Level assembly as required.

*Note:


Where the floor finish is such that no intermediate membrane is required, then all threaded joints must be sealed with an appropriate sealant and the supplied gasket must be fitted between the body and clamp collar.

DO NOT SCALE

THIRD ANGLE PROJECTION

IF IN DOUBT ASK !

© 2005

ISS. No.	3	4		DRAWN	M.S	03.05.06	TITLE	INSTALLATION GUIDELINES FOR GP3/6 SERIES GULLY	SCALE NTS	DRG. No. INSTAL 34	ISS. No. 4
C.N. No.	4174	4472		CHECKED							
DATE	23/7/09	25/11/11		APPROVED							
 WADE INTERNATIONAL LTD. THIRD AVENUE, HALSTEAD, ESSEX, CO9 2SX. TEL: 01787 475151 FAX: 01787 475579 e-mail: tech@wade.eu website: www.wade.eu				50910033							