


1. Before installation, position the body in the roof deck making allowance for membrane thickness. Ensure that outlet is accessible for pipework connection.
2. Install body such that the top face is flush or sub-flush with the underside of the membrane. Ensure body is fixed securely to the deck if not cast in.
3. Refer to membrane manufacturer's instructions and prepare flange with suitable primer. Apply membrane, dressing into sump of body as illustrated. Position grating and secure to body using appropriate supplied fixings, see below.

For membranes up to 19mm thick - use M6 x 40 Panhead screws (Wade Pt No 50902228)

For membranes over 19mm thick - use M6 x 50 Panhead screws (Wade Pt No 50902230)

See also the general installation guidelines in Wade 'Roof Outlets' Brochure.

© 2011

ISS. No.		DRAWN	DC	16-2-11	TITLE GENERAL INSTALLATION DETAIL FOR WF604 & WF704 BALCONY OUTLETS		
C.N. No.		CHECKED					
DATE		APPRVD.					
	Part Number	50910002			SCALE NTS	DRG. No. INSTAL 46	ISSUE No. 3

WADE INTERNATIONAL LTD., THIRD AVENUE, HALSTEAD, ESSEX, CO9 2SX.

TEL: 01787 475151 FAX: 01787 475579

e-mail: tech@wade.eu web site: www.wade.eu