


General Installation Instructions.

1. Remove grating from the grating assembly.
2. Position bottle trap in 4" bore of **grating frame**.
3. Tighten 4 expansion screws sufficiently to expand the seal ring such that it forms a watertight seal in bore.
4. Replace grating.

© 2013

| | | | | | | | |
|---|--|-------------|-----|---------|--|----------|-----------|
| ISS. No. | | DRAWN | GJD | 6-03-13 | TITLE TYPICAL INSTALLATION OF U1404 REMOVABLE BOTTLE TRAP | | |
| C.N. No. | | | | | | | |
| DATE | | CHECKED | AB | 21-3-18 | SCALE | DRG. No. | ISSUE No. |
|  | | PART NUMBER | | | INSTAL 50 | | 1 |
| | | 50910052 | | | | | |